



# Quick Reference Card


Please consult your spa user manual for complete info on the features of your spa system.



## in.k600


Advanced series of full-function keypads that give complete control to wet fingers!

Aeware's new series of keypads features a high profile with a large LCD display, menu-driven interface and raised keys that let users easily control all in.xm functions and programming directly from spa side, creating a true and unique user experience.




### Main Functions

- Setting Temperature
- Start Pump 1
- Start Pump 2
- Start Pump 3
- Start Light
- Starting Blower
- Economy Mode
- Standby Mode
- Display Time
- Progress Bars




This menu allows control of all pumps, blower and spa light, as well as the activation of the Economy and Standby modes. Every time a device is on, its animated icon is displayed. All pump activity can be stopped at once by activating the Standby mode.



• Press Mode key to display the mode Selection window.



• Select Spa to view Spa menu.



**Water temperature setting**


- Press Plus/Minus key to select water temperature setting.
- Press OK key or wait 5 seconds to confirm new setting. The "Set Point" prompt indicates the desired temperature NOT the current water temperature.



**Starting Light**

- Select Light key to turn light on.
- Select Light key repeatedly to control light intensity. A final selection turns light off.


(120 minute built-in timer)



**Starting Pump 1**

- Select Pump 1 to turn Pump 1 on.
- Select Pump 1 repeatedly to control pump 1 speeds.


(20 minute built-in timer)



**Starting Pump 2\***

- Select Pump 2 to turn Pump 2 on.
- Select Pump 2 repeatedly to control pump 2 speeds.


(20 minute built-in timer)



**Starting Pump 3\***

- Select Pump 3 to turn Pump 3 on.
- Select Pump 3 once more to turn pump 3 off.


(20 minute built-in timer)



**Next menu page**

- Press Next key to display the next page in the spa menu.


Goes to blower option



**Starting Blower\***

- Select Blower to turn Blower on.
- Select Blower once more to turn blower off.

(20 minute built-in timer)



**Turning Economy on**

Lowers the temperature set point of the spa by 20°F (11°C).

- Select Economy to activate the Economy mode.
- Select Economy again to override economy programming (see spa setup section).




**Standby Mode**

Stops all pumps at the same time by a simple click of a button!

- Select Standby to activate this mode.
- Select Standby to again to resume normal operations.


System automatically returns to Normal mode after a certain period of time, unless the Standby mode has been reactivated. Spa light will flash for a few seconds before the exit of Standby mode and restart the pumps. The "Standby" message is also displayed during Standby mode.

\* Pump will stay turned on if there is a request for more heat.



**Displaying time**

- Press Ok key to display the time.
- Press Ok key a second time to go back to water temperature display.



**Viewing active progress bars**

A progress bar is a visual indicator of the time remaining before a device is turned off. Only one bar is displayed at the time.

- Use Left or Right keys to visualize the progress bar of each activated device.

## Programming

- Filter cycles
- Economy Mode
- Reminders
- Warnings



### Programming spa system

To program the filter cycle, you must enter these parameters: start time, duration and frequency. During a filter cycle, pumps run for one minute to purge the plumbing, then Pump 1 runs for the programmed number of hours.

- Press Mode key
- Select Options menu
- Select Spa sub-menu
- Select Filter option



### Setting filter cycles start time

The display will show the starting hour previously set.


- Use (+) or (-) key to select hour setting.
- Use Right key to set minutes.
- Use (+) or (-) key to change minutes.
- Select Next arrow on screen menu to go to the next parameter: filter cycle duration.



### Setting cycle duration

Here we set a value for the filter cycle duration, in hours and minutes.


- Use (+) or (-) key to set hour setting.
- Use Right key to set minutes.
- Use (+) or (-) key to change minutes.
- Select Next arrow on screen menu to save changes and go to the next parameter: filter cycle frequency.



### Setting filter cycle frequency

Here we set the number of filtering cycles that the system will perform per day.

- Use (+) or (-) key to select frequency setting.
- Select Enter option on screen menu to save changes and go to back to spa options main menu.



### Setting Economy mode\*

- Select Economy



### Setting Economy status

- Use (+) key to enable the economy mode, the display will show **On**.
- Use (-) key to disable economy mode, the display will show **Off**.




### Setting Economy start time

- Select Next arrow on screen menu to save changes and go to economy cycle start hour.
- Use (+) or (-) key to set hour setting.
- Use Left key to access minutes option.
- Use (+) or (-) key to set minutes.
- Select Next arrow on screen menu to save changes and go to the next parameter stop economy.



### Setting Economy stop time


- Use (+) or (-) key to set hour setting.
- Use Left key to access minutes option.
- Use (+) or (-) key to set minutes.
- Select Enter option on screen menu to save changes and go to back to spa options menu.



### Setting maintenance reminder prompts


This menu allows you to activate/deactivate or simply reset the maintenance reminder prompts.

- Select Reminder option




### Turning reminders on/off\*

- Use (+) or (-) key to activate or deactivate prompt(s).
- Select Next arrow on screen menu to save changes and go to next menu screen.




### Resetting prompt messages

- Use Left or Right keys to review one by one all active maintenance messages.
- Select Enter option on screen menu to reset message and view next task or go back to main menu.



### Viewing spa reminders

The reminder icon will show up to prompt you to review active maintenance messages.



### Spa warnings


This menu allows for you to view all active warning messages ie.: hot water.

- Select Warning option



### Turning warnings on/off

- Use Left or Right keys to review all warning messages.
- Press Mode key again to go back to main menu.




### Viewing spa warnings

The warning icon shows up to prompt you to review active warning messages.

## Time setting

- Time of day



### Setting the time

- Press Mode key
- Select Options menu
- Select Clock setting




### Setting hour settings

- Use (+) or (-) key to set hour setting.
- Use Left or Right keys to access minutes option.
- Use (+) or (-) key to set minutes.
- Select Enter option on screen menu to back to keypad main menu.


## Other Settings

- Keypad display
- Sound
- Regional
- Security



### To program keypad settings


- Press Mode key
- Select Options menu
- Select Keypad sub-menu



### Setting keypad display options


This sub-menu is used to set keypad display settings such as: contrast, backlight, etc.

- Select Display options




### Adjusting contrast

- Use Left or Right keys to adjust desired level of contrast.
- Select Next arrow on display to save changes and go to next screen menu.




### Adjusting backlight

- Use Left or Right keys to adjust backlight brightness.
- Select Next arrow on display to save changes and go to next screen menu.




### Normal/Reverse display

- Use (+) or (-) key to activate or deactivate reverse display.
- Select Next arrow on display to save changes and go to next screen menu.



### Display orientation (inverting)


- Use (+) or (-) key to activate or deactivate reverse display.
- Select Enter option on screen menu to back to keypad main menu.



### Setting keypad audio options

This sub-menu is used to set keypad audible options setting such as: keypad on (key beep) and alarm.

- Select Sound options




### Keypad beep on/off

- Use (+) or (-) key to activate or deactivate reverse display.
- Select Next arrow on display to save changes and go to next screen menu.



### Turning alarm sound on


- Use (+) or (-) key to activate or deactivate alarm sound.
- Select Enter option on screen menu to save changes and go back to main menu.



### Setting regional settings


This sub-menu is used to set keypad regional settings such as: language, select temperature display units and choose a format for time display.

- Select Regional options



### Setting language


- Use (+) or (-) to select from: English, Français Spanish & Deutsch
- Select Next arrow on display to save changes and go to next screen menu.



### Temperature units


Water temperature can be displayed in °F or °C.

- Use (+) or (-) to change setting.
- Select Next arrow on display to save changes and go to next screen menu.



### Selecting time format


- Use (+) or (-) to change setting.
- Select Enter option on screen menu to save changes and go back to keypad main menu.



### Security options


Partial keypad lock: basic functions of the spa remain accessible (pump and light outputs) but it's impossible to change the temperature Set Point, or to enter Programming mode. Full lock: all keys are disabled. When the keypad is locked, the icon will be displayed.

- Select Security options



### Partial keypad lockout

- Use (+) or (-) key to select "Partial".
  - Select Enter option on screen menu to back to keypad main menu.
- To unlock the keypad:
- Select Mode key
  - Press and hold Option key for 5 seconds




### Full keypad lockout

- Use (+) or (-) key to select "Full".
  - Select Enter option on screen menu to back to keypad main menu.
- To unlock the keypad, press and hold Light key for 5 seconds.

## System info

- Spa
- Heater
- Keypad
- Reset
- Upgrade



### Viewing information about the system

To view spa equipment data such as: system, heater and keypad software version, to reset programmed settings and to upgrade keypad software.

- Press Mode key
- Select Options menu
- Select Info sub-menu



### Viewing information about spa

Spa software ID number and version are displayed.


- Select Next arrow on display to next screen menu.



### Viewing information on heater software

Heater software ID number and version are displayed.


- Select Next arrow on display to next screen menu.



### Viewing information on keypad software

Keypad software ID number and version are displayed.

- Select Next arrow on display to next screen menu.



### Resetting keypad programmed values

- Press Ok to reset back to default factory values.
- Select Next arrow on display to next screen menu.



### Upgrading keypad software

- Use Ok key to start the upgrade of the software of the keypad.
- Select Enter option on screen menu to back to keypad main menu and not upgrade the software of the keypad.

\*option available depending upon factory settings